

IMS-4000 PowerGate2



Description

The IMS-4000 PowerGate2 allows you to manually or automatically switch up to 8 electrical outlets from the IMS-4000 ConsoleView Software or the IMS-4000 web page. This gives you the ability to remotely turn-on, turn-off, or cycle power (reboot) remote equipment. You can also program the system to automatically control the power to a device based on an alarm condition. The PowerGate2 features individual power input circuits for each outlet thus giving you the ability to distribute the power load across multiple circuits. Two of the outlets can switch up to 10 amps (120VAC 60Hz) and the other six can switch up to 4 Amps (120VAC 60Hz). The unit is made for rack mounting with steel brackets and fits in a 1 EIA rack space (17”w x 12”d x 1.75”h).

Package Contents

- (1) IMS-4000 PowerGate2
- (1) Power Cord
- (1) Serial Cable
- (1) Instruction Manual
- (1) Rack Mounting Brackets & Hardware
- (1) Right Angle Power Cord (IMS-4413)

Description

Part Number

IMS-4000 PowerGate2	IMS-4302
Right Angle Power Cord for PowerGate2	IMS-4413

